FIELD REPLACEABLE UNIT DOCUMENTATION Sate llite™

2610/2750 Series

BATTERY PACK REMOVAL



- Turn the computer upside down as shown
 Stide the hattern release lower, in the direction of the
- 3 Slide the **battery assembly** towards you and lift if out

OPTIONAL PCMCIA CARD REMOVAL



- Eyect button PC card

 1 Pull out the eyect button of the PC card to be removed.
 2 Press the eyect button and remove the PC card.
 - NOTE Before removing any PCMCIA device make sure it is STOPPED in the PC Card Manager

HDD REMOVAL



HDD slot cover

- 1 Turn the computer upside down 2 Remove one M2.5x8 black screw/securing HDB
- 2 Remove one M2.5xii black screwsecuring cover and pull out the cover



HDD bracket HDD

- Slide the HBB forward to disconnect from PJ9 on the system board
 - 4 Lift out the HDD

TOSHIBA

FIELD REPLACEABLE UNIT DOCUMENTATION Sate llite™

2610/2750 Series

2610/2/30 Series

Latch

KEYBOARD REMOVAL



Keyboard holder

1. Open the display panel

2. Remove the keyboard holder at the top of the keyboard.

KEYBOARD REMOVAL



M2x4 brass screw Keyboard

3. Remove two M2x4 brass screws securing the

 Remove two M2x4 brass screws securing the keyboard
 Lift out the keyboard and key it face down on the pair.

cable

KEYBOARD REMOVAL



5 Disconnect the **keyboard cable** from PJH4 on the system board and remove the **keyboard**

ODEM REMOVAL



M2x4 brass screws PJ/01 Modem cable
1 Remove two M2x4 brass screws securing the

- modern board

 2 Lift up the front side of the **modern board** and remove
- t from the system board
 3 Disconnect the modern cable from PJ701 on the modern

TOSHIBA

FIELD REPLACEABLE UNIT DOCUMENTATION Satellite[™]

2610/2750 Series



Memory dips 1. Gently push the memory dips outward and pull the memory module out of the connector on a

TOP COVER REMOVAL

LED Internet match LCD/FL cable PJ13 CD/PS switch cable Right speaker cable Left speaker

M2 5x6 brass screws SealM2v4 black screws 2. Turn the computer nont side up and open the display panel 3 Remove two tapes securor the speaker pables

LCD.FL cable from P.D CDJPS switch cable from PJ13

Left and Right speaker cable from PJ19 and PJ29 LEB/Internet switch cable from PJ24 5 Remove the seal covernor for screward remove one

M2x4 black scrnward thron M2.5x6 brass scrnws.

TOP COVER REMOVAL

M2 5x6 black screws M2 5x8 black screws

M2 5x20 black screws

 Turn the computer upade down and remove the following thateen screws 2 M2.5x28 black screws

6 M2.5x8 black screws 5 M2,5x6 black screws from battery slot and back of the computer

SealM2xil black screw



6. Left up the back race of the top cover and display. assembly and pass the modern tack through the opening in the upper cover

CAUTION: When installing the top cover make sure that the modern sack cable is routed properly through the opening of the ton course

TOSHIBA Tough Enough for Today's World.

cable

FIELD REPLACEABLE UNIT DOCUMENTATION SateIlite[™]

2610/2750 Series

FDD REMOVAL



1. Disconnect the FDD flexible cable from PJ7 on the system hoard 2 Remove the FRR

EDD. SCHOOL FDD

3 Remove four M2.5x3 black screws securing the FDD to the EDD case and separate the EDD from its case. 4. Disconnect the FBB flexible cable from the FDD.

CD ROMOVO ROM DRIVE REMOVAL



CD/DVD ROMdove

- 1 Carefully lift up the back side of the CD ROMB VD-ROM drive and remove it from PJ18 on the system board
- CD-ROM drive Sale brace CD ROM/DVD-ROM CD ROMOVO ROM M2x3 screws M2x6 brass screws
 - 2 Remove two M2x6 brass screws securing the
 - CD-ROM/DVD ROM connector board 3 Separate the CD ROMDVD ROM connector board and CD-ROMD VD-ROM connector brace from the
 - 4 Remove two M2x3 silver screws securing the ade brace on the CD ROMD VD-ROM drive

FIELD REPLACEABLE UNIT DOCUMENTATION Satellite™

2610/2750 Series

COOLING FAN REMOVAL



PJE

Loosen four flat head brase screws securing the cooling fan
 Remove the cooling fan and disconnect the fan cable.

Fan cable

RTC BATTERY REMOVAL



 Remove the tape securing the RTC battery
 Disconnect the RTC battery cable from PJ12 on the system board
 Lift out the RTC battery

Trom PJ6 on the system board SYSTEM BOARD REMOVAL



 Release the latches securing the modern pack and remove it.
 Release the latches securing the audio jack panel and remove it. M2 56 Ireas sovere

System board

Remove **eight M2.5x6** bress screws securing the system board and power supply board.

It if not the plastic switch cover.

TOSHIBA

FIELD REPLACEABLE UNIT DOCUMENTATION SateIlite[™]

2610/2750 Series

SYSTEM BOARD REMOVAL



Power supply board System board

5 Lift up the systemboard and power supply board from the front ade and pull them out. Ensure that the eject buttons of the PC Card Slot is not caught on the bottom cover

6 Lift out the PC Card Slot cover

MEMBRANE SWITCH REMOVAL IPS switch assembly



Remove three M2x4 black screws securing the 2 Lift out the IPS switch assembly

SPEAKERS REMOVAL



M 2x4 bress screve 1 Remove two M2x4 brase screws securing each

 Remove the tane seguing the speaker cables and lift out the speakers

TOSHIBA Tough Enough for Today's World.

FIELD REPLACEABLE UNIT DOCUMENTATION Sate llite™

2610/2750 Series

DISPLAY MASK REMOVAL

Cogniy mask

- Mask seals

 Remove two mask seals at the bottom corners of the deplay acceptally
- 2. Remove two M256F bress screws 3. There are 28 letches securing the display mask Carefully most your fingers between the display mask and the LCD module and pryopen the letches starting from the top sax latches; to the fine latches on the right and left sides entities with the sax bottomistiches.

FL INVERTER AND LCD REMOVAL



- 1 Remove all tapes and one M2x4 brass screw
- securing FL inverter board

 2 Carefully 1 true the FL inverter board and disconnect the FL inverter cable from CN1 and
- the HV cable from CN2

 3 Remove four M2.5x6 brass screws securing the
 - Carefully rotate the LCD module from right to left of the LCD cover
 Disconnect the LCD cable from the LCD module and remove the LCD module from the consister.

TOSHIBA